



WIREMOLD
FOR 500 RACEWAY **605 RACEWAY CUTTER**

1. OPEN BLADE AND INSERT TOP OF RACEWAY FACING PIVOT
2. BRING HANDLE DOWN THROUGH RACEWAY IN ONE EVEN CUT UNTIL IT BOTTOMS
3. USE PLIERS TO RESHAPE AND DEBURR IF NECESSARY



WIREMOLD
605 RACEWAY CUTTER
FOR 500 RACEWAY

1. OPEN BLADE AND INSERT TOP OF RACEWAY FACING PIVOT
2. BRING HANDLE DOWN THROUGH RACEWAY IN ONE EVEN CUT UNTIL IT BOTTOMS NECESSARY
3. USE PLIERS TO RESHAPE AND DEBURR IF NECESSARY