

Push Buttons

Push Button Plates

147 and 149 Series

The Edwards 147-1 Push Button Plate is used for mounting 620 and 690 series 5/8" (16mm) buttons on a standard single gang box.

The Edwards 149-1 Push Button Plate is used for mounting 821, 850, and 854 series 7/8" (22mm) buttons on a standard single gang box.

Features and Specifications

- Standard switch box mounting
- Stainless steel faceplate
- Single gang




Ordering Information

| Description | Cat. No. | For Use With |
|--------------------------------------|----------|-------------------------|
| Mounting Plate for 5/8" Push Buttons | 147-1 | 620 and 690 Series |
| Mounting Plate for 7/8" Push Buttons | 149-1 | 821, 850 and 854 Series |

Weights and Dimensions

| Cat. No. | Approx. Net Weight (lb.) | Approx. Shipping Weight (lb.) |
|----------|--------------------------|-------------------------------|
| 147-1 | 0.12 | 0.15 |
| 149-1 | 0.12 | 0.15 |



Push Buttons

Push Button Plates

147 and 149 Series

The Edwards 147-1 Push Button Plate is used for mounting 620 and 690 series 5/8" (16mm) buttons on a standard single gang box.

The Edwards 149-1 Push Button Plate is used for mounting 821, 850, and 854 series 7/8" (22mm) buttons on a standard single gang box.

Features and Specifications

- Standard switch box mounting
- Stainless steel faceplate
- Single gang



Ordering Information

| Description | Cat. No. | For Use With |
|--------------------------------------|----------|-------------------------|
| Mounting Plate for 5/8" Push Buttons | 147-1 | 620 and 690 Series |
| Mounting Plate for 7/8" Push Buttons | 149-1 | 821, 850 and 854 Series |

Weights and Dimensions

| Cat. No. | Approx. Net Weight (lb.) | Approx. Shipping Weight (lb.) |
|----------|--------------------------|-------------------------------|
| 147-1 | 0.12 | 0.15 |
| 149-1 | 0.12 | 0.15 |

