

U1252-X-5T-K1



U1252-X-5T-K1
5 Terminal Ringless Large Closing Plate 2 Position Single Connector 4-600kcmil
784572133310
5.125
26.5
14
Milbank
Ringless Meter Socket
Meter Socket
UL Listed;Type 3R
300 Volts Alternating Current
200 Continuous Ampere
1 Phase
60 Hertz
00 110112
5.125L x 26.5W x 14H
5.125L x 26.5W x 14H
5.125L x 26.5W x 14H 0
5.125L x 26.5W x 14H 0 No Main Breaker Overhead or Underground
5.125L x 26.5W x 14H 0 No Main Breaker Overhead or Underground with Center Wireway

Enclosure	G90 Galvanized Steel with Powder Coat Finish
Jaw Quantity	5 Terminal
Bypass Type	No Bypass
Number of Meter Positions	2 Positions
Equipment Ground	Ground Lug
Hub Opening	Large Closing Plate
Line Side Wire Range	6 AWG - 350 kcmil
Load Side Wire Range	6 AWG - 350 kcmil
Number Of Receptacles	0

Please consult serving utility for their requirements prior to ordering or installing, as specifications and approvals vary by utility and may require local electrical inspector approval. All installations must be installed by a licensed electrician and must comply with all national and local codes, laws and regulations. Milbank reserves the right to make changes in specifications and features shown without notice or obligation.



U1252-X-5T-K1



U1252-X-5T-K1
5 Terminal Ringless Large Closing Plate 2 Position Single Connector 4-600kcmil
784572133310
5.125
26.5
14
Milbank
Ringless Meter Socket
Meter Socket
UL Listed;Type 3R
300 Volts Alternating Current
200 Continuous Ampere
1 Phase
60 Hertz
00 110112
5.125L x 26.5W x 14H
5.125L x 26.5W x 14H
5.125L x 26.5W x 14H 0
5.125L x 26.5W x 14H 0 No Main Breaker Overhead or Underground
5.125L x 26.5W x 14H 0 No Main Breaker Overhead or Underground with Center Wireway

Enclosure	G90 Galvanized Steel with Powder Coat Finish
Jaw Quantity	5 Terminal
Bypass Type	No Bypass
Number of Meter Positions	2 Positions
Equipment Ground	Ground Lug
Hub Opening	Large Closing Plate
Line Side Wire Range	6 AWG - 350 kcmil
Load Side Wire Range	6 AWG - 350 kcmil
Number Of Receptacles	0

Please consult serving utility for their requirements prior to ordering or installing, as specifications and approvals vary by utility and may require local electrical inspector approval. All installations must be installed by a licensed electrician and must comply with all national and local codes, laws and regulations. Milbank reserves the right to make changes in specifications and features shown without notice or obligation.