



























Front-Mount Auxiliary Contacts for Use with XTRE Control Relays ^①

| | Conventional Thermal Current, I_{th} (A), Open at 60°C | Poles | Rated Operational Current AC-15 I_e (A) | | | Contact Configuration | Circuit Symbol | Pkg. Qty. ^② | Screw Terminal Catalog Number |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------|-------|-------------------------------------------|----------------------|------|-----------------------------------------------|---------------------------------------------------------------------------------------|------------------------|-------------------------------|
| | | | 220V 230V 240V | 380V 400V 415V | 500V | | | | |
| Two-Pole  | 16 | 2 | 6 | 3 | 1.5 | 2NO |  | 5 | XTCEXFAC20 |
| | 16 | 2 | 6 | 3 | 1.5 | 1NO-1NC |  | 5 | XTCEXFAC11 ^③ |
| | 16 | 2 | 6 | 3 | 1.5 | 2NC |  | 5 | XTCEXFAC02 |
| | 16 | 2 | 6 | 3 | 1.5 | 1NO _E -1NC _L |  | 5 | XTCEXFALC11 ^④ |
| Four-Pole  | 16 | 4 | 6 | 3 | 1.5 | 4NO |  | 5 | XTCEXFAC40 ^③ |
| | 16 | 4 | 6 | 3 | 1.5 | 3NO-1NC |  | 5 | XTCEXFAC31 ^③ |
| | 16 | 4 | 6 | 3 | 1.5 | 2NO-2NC |  | 5 | XTCEXFAC22 ^③ |
| | 16 | 4 | 6 | 3 | 1.5 | 1NO-3NC |  | 5 | XTCEXFAC13 |
| | 16 | 4 | 6 | 3 | 1.5 | 4NC |  | 5 | XTCEXFAC04 |
| | 16 | 4 | 6 | 3 | 1.5 | 1NO-1NC 1NO _E -1NC _L |  | 5 | XTCEXFALC22 ^④ |
| | 16 | 4 | 6 | 3 | 1.5 | 1NO-1NC 1NO _E -1NC _L |  | 5 | XTCEXFALC22 ^④ |

Notes

- ① Interlocked opposing contacts, to IEC/EN 60947-5-1 Annex L (positively driven), within the auxiliary contact modules (not NO_E and NC_L contacts) and between the auxiliary contacts and built-in contacts of the XTRE control relays.
- ② Orders must be placed in multiples of package quantity listed.
- ③ Catalog number is shown with screw type terminal. For spring cage, add a "C" before the last 2 digits. For example, to order a spring cage version of the XTCEXFAC22, change the catalog number to XTCEXFACC22.
- ④ One early-make contact (NO_E), one late-break contact (NC_L).

Front-Mount Auxiliary Contacts for Use with XTRE Control Relays ^①

| | Conventional Thermal Current, I_{th} (A), Open at 60°C | Poles | Rated Operational Current AC-15 I_e (A) | | | Contact Configuration | Circuit Symbol | Pkg. Qty. ^② | Screw Terminal Catalog Number |
|-------------------------------------------------------------------------------------------------------|----------------------------------------------------------|-------|-------------------------------------------|----------------------|------|-----------------------------------------------|---------------------------------------------------------------------------------------|------------------------|-------------------------------|
| | | | 220V 230V 240V | 380V 400V 415V | 500V | | | | |
| Two-Pole  | 16 | 2 | 6 | 3 | 1.5 | 2NO |  | 5 | XTCEXFAC20 |
| | 16 | 2 | 6 | 3 | 1.5 | 1NO-1NC |  | 5 | XTCEXFAC11 ^③ |
| | 16 | 2 | 6 | 3 | 1.5 | 2NC |  | 5 | XTCEXFAC02 |
| | 16 | 2 | 6 | 3 | 1.5 | 1NO _E -1NC _L |  | 5 | XTCEXFALC11 ^④ |
| Four-Pole  | 16 | 4 | 6 | 3 | 1.5 | 4NO |  | 5 | XTCEXFAC40 ^③ |
| | 16 | 4 | 6 | 3 | 1.5 | 3NO-1NC |  | 5 | XTCEXFAC31 ^③ |
| | 16 | 4 | 6 | 3 | 1.5 | 2NO-2NC |  | 5 | XTCEXFAC22 ^③ |
| | 16 | 4 | 6 | 3 | 1.5 | 1NO-3NC |  | 5 | XTCEXFAC13 |
| | 16 | 4 | 6 | 3 | 1.5 | 4NC |  | 5 | XTCEXFAC04 |
| | 16 | 4 | 6 | 3 | 1.5 | 1NO-1NC 1NO _E -1NC _L |  | 5 | XTCEXFALC22 ^④ |
| | 16 | 4 | 6 | 3 | 1.5 | 1NO-1NC 1NO _E -1NC _L |  | 5 | XTCEXFALC22 ^④ |

Notes

- ① Interlocked opposing contacts, to IEC/EN 60947-5-1 Annex L (positively driven), within the auxiliary contact modules (not NO_E and NC_L contacts) and between the auxiliary contacts and built-in contacts of the XTRE control relays.
- ② Orders must be placed in multiples of package quantity listed.
- ③ Catalog number is shown with screw type terminal. For spring cage, add a "C" before the last 2 digits. For example, to order a spring cage version of the XTCEXFAC22, change the catalog number to XTCEXFACC22.
- ④ One early-make contact (NO_E), one late-break contact (NC_L).